
- 1. Plasticlid
- 2. Frontguard
- 3. Mounting nut
- 4. Fan blade
- 5. Mounting nut
- 6. Back guard
- 7. Motor shaft
- 8. Motor
- 9. Motor housing
- 10. Oscillaatin knob
- 20. Adjustment nut
- 21. Lock sprain
- 22. Upper pipe
- 23. Pipe connector
- 24. Lower pipe
- 25. Cover
- 26. Crossbase
- 27. Foot
- 28. Switch compartment
- 30. Switches
- 31. ON/OFF



## **Assembly**

- 1. Secure lower pipe with pipe support to the hub of cross base with screw provided.
- 2. Extend upper pipe, insert the pipe connector through upper pipe onto lower pipe and tighten.
- 3. Attach the motor with switch compartment onto the upper pipe. Ensure the switch compartment is pushed fully onto the upper pipe and secured with the screw provided.
- 4. Position back guard firmly to motor housing and then fasten by turning guard mounting nut clockwise tightly.
- 5. Push the blade along motor shaft and fasten firmly with the blade.
- 6. Hang the front guard to back guard with the position fixer provided at the rim of guard, and then fix together with clips provided.